

Fixed Cellular Terminal

Model: FCT



We extend a warm welcome to you on becoming a part of the Copper Connections family. Our service support Engineers shall be working hard through our channel partners to ensure your satisfaction with the product and after sales services. We welcome your feedback / query at cclserviceccl@gmail.com

Contents

Installation
 Technical Specifications
 Terms of Warranty

Note:

- Copper Connections Ltd reserves the right to alter equipment specifications and descriptions contained herein and make no commitment to update or keep current the information herein. All information herein is subject to change at any time without notice. No part of this publication shall be deemed to be part of any contract or commitment whatsoever.
- Product specifications and features are subject to changes without prior notice due to our constant endeavor to improve the product.

Installation

- Insert SIM Card in the SIM Socket at the back side of system
- Connect wires labeled as "12V Adptr +" and " - " to the +ve (Red) and -ve (White) of 12V DC Adaptor.
- The two wires labeled as "To Telephone Set" are to be connected to the telephone set or Junction port of PBX

LED Indications :

Armed LED: The blinking of this LED indicates that System is powered by 12V Adaptor

Ready LED: This LED indicates the GSM signal strength. Following are the three possibilities:

- Continuously ON – Signal Strength is GOOD (Above 18)
- Blinking – Signal Strength is MODERATE (Between 13 & 18)
- LED is OFF – Signal Strength is LOW (Below 13)

STD Code Addition

While dialing landline numbers, if the STD code is required to not be inserted each time, the following programming can be done to automatically insert a specified STD code before the number being dialed.

*01 LL XXXXX # where LL = Number of digits of telephone number without STD code
 XXXXX = STD code to be added (Maximum 5 digits)

For eg: To insert STD code 011 for telephone number 23432433programming will be

*01 08 011 #

Where 08 is the number of digits in telephone number and 011 is the STD code to be added.

To Reset STD Code Addition : *01 9999 #

CLI DTMF Level Increase/ Decrease

If CLI from FCT is not being received on telephone set/PBX, the level of CLI can be altered.

*02 XX # where XX is the level from 20 to 99.

Default value is 40.

CLI Digit Deletion

If the last 1 or 2 digits of CLI are not received on telephone set/PBX, the then total number of digits of CLI can be altered.

*03 X # where X = 0-2.

If X=0, no digits are removed from CLI being sent from FCT.

If X=1, 1 digit is removed from the beginning of CLI being sent from FCT.

If X=2, 2 digits are removed from the beginning of CLI being sent from FCT.

Technical Specifications

Operating Voltage	12V DC
Standby current	130 mA - 170 mA
Current during talk	320 mA – 410 mA
Power Adapter	12V DC 1A
GSM Module	Quad Band - GSM 850/ 900/ 1800/ 1900 MHz Operating Volatge:3.3~4.6V 4.0V Support SIM Card: 1.8V/3.0V

Terms of Warranty

Copper Connections Ltd warrants that this product is manufactured under stringent quality standards, making it free from defects in material and workmanship, as per the following terms and conditions:

1. The limited warranty for the system is valid for a period of twelve months from the date of purchase or fifteen months from the date of manufacture which ever is earlier.
2. The limited warranty extends only to the original consumer/ purchaser of the product and is not assignable or transferable to any subsequent purchaser/ end user.
3. During the limited warranty period, Copper Connections Pvt. Ltd or its authorised service network will repair or replace, at Copper Connections Pvt. Ltd option, any defective product or parts thereof with a new or factory rebuild replacement items and return the product to the consumer in working conditions. No charge will be made to the consumer for either parts or labour in repairing or replacing the product. All replaced parts shall becomes the property of Copper Connections Pvt. Ltd.
4. Repaired product will be warranted for a balance of original warranty period.
5. Upon request from Copper Connections Pvt. Ltd or its authorised service center, the consumer must provide purchase receipt or other information to prove the date and place of purchase.
6. This Burglar Alarm System (like any other commercial or residential alarm system) does not guarantee protection against burglary, fire or other emergency because of variety of reasons.
A properly installed and maintained system may reduce the risk of a burglary, robbery, fire or other events, but it is not an insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result.
7. In no case shall seller be liable to anyone for any consequential or incidental damages for breach of this warranty, even if the loss or damage is caused by the seller's own negligence or fault. Consequently, seller shall have no liability for any personal injury, property damage or other loss based on a claim "The product failed to give warning / alarm". However, if seller is held liable, whether directly or indirectly, for any loss or damage arising under this warranty or otherwise regardless of cause, seller's maximum liability shall not in any case exceed the purchase price of the product.
8. The consumer shall have no benefit or coverage if any of the following conditions are applicable:
 - a) The product has been subjected to abnormal use, abnormal condition, improper storage, exposure to excessive Temperature, moisture, dampness or fire etc., unauthorised modifications, unauthorised connections, unauthorised repairs.
 - b) Copper Connections Pvt. Ltd was not notified by consumer of the alleged defect or malfunction of the product during the limited warranty period.
 - c) The product was used with or connected to equipment not fit for use with Copper Connections Pvt. Ltd system or used in other than its intended use.
 - d) **INCASE HIGH VOLTAGES APPEAR ON EARTH.**
 - e) **THE DAMAGE IS CAUSED BY LIGHTENING OR DUE TO SPIKES/ SURGES/ HIGH VOLTAGES FROM AC MAIN SUPPLY.**
9. The consumer may contact the authorised dealer to call the service personnel for carrying out repairs or maintenance and the same would be attended within a reasonable response time assigned to the dealer. The consumer will be billed for parts or labour charges not covered by this limited warranty.
10. The consumer will be billed for parts or labour charges not covered by this limited warranty.
11. If the product is brought to Copper Connections Pvt. Ltd for repairs, after the warranty period , Copper Connections Pvt. Ltd normal service policy shall apply and customer shall be charged accordingly.
12. In no event shall Copper Connections Pvt. Ltd or their authorised dealer be liable for special or consequential damages or any delay in the performance of this warranty due to causes beyond their control. Copper Connections Pvt. Ltd shall not be liable for incidental or consequential damage or a loss of anticipated benefits or profits, loss or impairment of privacy of conversation, work stoppage or loss or impairment of data arising out of the use or inability to use the product. Company's liability in no event and under no circumstances shall exceed the price paid to the company for goods stated in the invoice.
13. Copper Connections Pvt. Ltd neither assumes nor authorises any authorised service center or any person or entity to assume for it any other obligation or liability beyond what is expressly provided by this limited warranty. All warranty information, product features and specifications are subject to change without prior notice.
14. Any dispute arising out of this warranty shall be subjected to jurisdiction of the arbitrator within the city of Delhi.
15. The decision of Copper Connections Pvt. Ltd on defects, damages etc shall be final and binding on the parties and no dispute regarding this, could be agitated before any civil court.

Part No: FCT - 4

An ISO:9001:2015 Certified Company
Copper Connections Ltd.

B-221, Okhla Industrial Area, Ph-1, New Delhi-110020. Ph: +91-11-40625555

www.copperconnections.com